



NOTES:

1. SAWCUT SHALL BE LOCATED ALONG THE EXISTING EDGELINE SUCH THAT A MINIMUM OF 1 FT OF THE EXISTING FULL DEPTH PAVEMENT IS REMOVED AND REPLACED, FOR A PROPER JOINT.
2. REFER TO 15.8 FOR PAVING GUIDELINES.

TYPICAL SHOULDER  
REMOVAL AND FULL DEPTH  
WIDENING ENGINEERING  
ACCESS PERMITS